Add Manually paved area

1 Press the "Load" button to access the Load menu

2 Enter the area of the manually paved area you want to add

3 Press " " to register the area



After adding the manually paved area, a list of manually paved areas will be displayed briefly on the bottom screen. The list can also be accessed by using the arrow buttons right and left, when in the "Load" menu.

The " " button can be used to adjust the size of the area, if an area too large has been entered into the system

Export Data

1 Press the "Export" button to access the Export menu and insert the MatManager™ USB stick that came with the system

2 Select the job you wish to export in the dropdown menu. Press and hold with you finger and the list of job opens. Slide your finger down to the job you wish to select, and release

3 Press "Export log to file" to export raw logged data to a file that can be opened and further processed in MatWiser™ on a pc

4 Press "Export report to file" to export a predefined report file, that can be opened and printed from a pc



Find the full User Manual in our Paving Academy: www.tf-technologies.com/Paving-Academy. The manual can be downloaded from our website, or you can order a free copy by sending an email to sales@tf-technologies.com

MatManager™

Quick Guide to Daily Operation

TF TECHNOLOGIES
PAVING INNOVATION

MatManager™ Quick Guide
Daily Operation

Start a new job

1 Press the "Job" button to access the Job menu

2 Enter information using the keyboard on the screen
Material ID, Paver ID, Crew & Density is optional

3 Press "Create new job" to create the new job

After creating a new job you will be taken to the Home screen and the job starts.
The new job is added to the list of jobs.

Delete job

It is not possible to delete the current job.
End the current job, to be able to delete it.

4 End current job

5 Delete job

Select a previously created job

1 Press the "Job" button to access the Job menu

2 Activate the dropdown menu by pressing and holding "Select Job ID"

3 Move your finger down to the job you want to select and press "Select existing job"

After selecting a previously created job you will be taken to the Home screen and the job starts.



Enter load, modify load or scrap material

1 Press the "Load" button to access the Load menu

2 Enter load in kg using the keyboard on the screen
Reference code is optional

3 Press "Add load" to register the load **or**

4 Press "Update load" to modify the current load **or**

5 Press "Scrap material" to register that an amount of the material has been scrapped



After registering or modifying a load, the load list will be displayed for 4 sec. and then return to the job.

After scrapping material, a list of scrapped material will be displayed briefly in the bottom view.

The list of loads can be accessed by using the arrow buttons right and left, when in the "Load" menu.

Copyright All information, text and pictures are the intellectual property of, and copyrighted material of TF-Technologies A/S. **Disclaimer** Before MatManager™ is operated, the full user manual should be studied carefully to ensure correct and safe use of the system.TF-Technologies A/S and its distributors may not be held liable for potential editorial errors, omissions or failure effects. **Quick Guide Information** Document name: MatManager™ Quick Guide - Document number: G704802 - Publication date: 05. September 2017. This Quick guide refers to Firmware 1.2.0. **TF-Technologies A/S** - Kratbjerg 214 - 3480 Fredensborg - Denmark - Phone: +45 48 48 26 33 - Email: sales@tf-technologies.com - www.tf-technologies.com.